

Model PG70ABDL

Precision Gauge

Operating Instructions



This product meets the Electromagnetic Compatibility Directive.

The product is Class A, Group 1 ISM equipment according to CISPR 11

Group 1 ISM product: A product in which there is intentionally generated and/or used conductively coupled radio-frequency energy which is necessary for the internal functioning of the equipment itself.

Class A product are suitable for use in all establishments other than domestic and those directly connected to a low voltage power supply network which supplies buildings used for domestic purposes.

Note: In the close presence of some radio transmitters, erroneous readings may be given. If this occurs tests should be repeated at another location.

These operating instructions are available for download on our website www.elcometerNDT.com. These operating instructions are available in a number of languages. For the avoidance of doubt, please refer to the English language version.

The following trademark is a registered trademark of Elcometer Limited, Edge Lane, Manchester, M43 6BU. United Kingdom:



Material Safety Data Sheets for the ultrasonic couplant supplied with the PG70ABDL and available as an accessory, are available to download via our website:

Elcometer Ultrasonic Couplant Material Safety Data Sheet :

www.elcometer.com/images/MSDS/elcometer_ultrasonic_couplant.pdf

www.elcometer.com/images/MSDS/elcometer_ultrasonic_couplant_blue.pdf

Elcometer Ultrasonic Couplant (High Temperature) Material Safety Data Sheet :

www.elcometer.com/images/MSDS/elcometer_ultrasonic_couplant_hi_temp.pdf

All other trademarks acknowledged. © Elcometer Limited 2011-2014. All rights reserved. No part of this document may be reproduced, transmitted, transcribed, stored (in a retrieval system or otherwise) or translated into any language, in any form or by any means (electronic, mechanical, magnetic, optical, manual or otherwise) without the prior written permission of Elcometer Limited.

Contents

1	About your Gauge	3
2	The Keypad	4
3	Getting Started	5
4	The Menu	5
5	The Measurement Screen	7
6	Measurement - Modes	10
7	Setting Up the Gauge	12
8	Measurement - Taking Readings	14
9	Gates	15
10	ThruPaint™ Measurement Technique	16
11	Measurement - Options	16
12	Measurement - Recording your Readings	17
13	Gauge Setups	20
14	Data Transfer Software	21
15	Storage	22
16	Maintenance	22
17	Technical Specification	23
18	Warranty	24
19	Spares & Accessories	24
20	Condition and preparation of surfaces	25
21	Application notes	25
22	Sound Velocities of Common Materials	26
23	The Menu Commands	27

Thank you for purchasing this Elcometer NDT product. Welcome to Elcometer NDT.

The Elcometer PG70ABDL Precision Gauge is a world beating product. With the purchase of this gauge you now have access to the worldwide service and support network of Elcometer NDT. For more information visit our website at www.elcometerNDT.com

1 ABOUT YOUR GAUGE

The Elcometer PG70ABDL is a precision gauge that measures with extreme versatility. It has the ability to measure coatings and material thickness simultaneously while maintaining the ability to locate pits, flaws and defects in the material. Based on the same operating principles as SONAR, the Elcometer PG70ABDL is capable of measuring the thickness of various materials with accuracy as high as +/-1% or +/-0.02 millimetres (+/-0.001 inches) whichever is the greater. The principal advantage of ultrasonic measurement over traditional methods is that ultrasonic measurements can be performed with access to only one side of the material being measured.

The Elcometer PG70ABDL includes a data-logging (memory) facility which allows readings to be stored in batches before being downloaded to a computer.

1.1 STANDARDS

Your gauge can be used in accordance with the following Standards and test methods; ASTM E 797, EN 14127 and EN 15317.

1.2 WHAT THIS BOX CONTAINS

Elcometer PG70ABDL, Bottle of couplant, Battery (3 x), Carrying case, Test Certificate, Operating instructions, CD with software to enable you to transfer your readings and settings to and from a PC, RS232 cable and USB to serial converter.











*Note: The box does **not** include a transducer; these must be ordered separately. To order a transducer, contact Elcometer NDT or your local Elcometer NDT supplier.*

1.3 PACKAGING

The gauge is packed inside its carry case within a cardboard box. Please ensure that the packaging is disposed of in an environmentally sensitive manner. Consult your Local Environmental Authority for further guidance.

To maximise the benefits of your new Elcometer NDT gauge, please take some time to read these Operating Instructions. Do not hesitate to contact Elcometer NDT or your Elcometer NDT supplier if you have any questions.

2 THE KEYPAD

	<p>Activates the primary menu structure containing 9 menu tab groups. These tab groups then contain sub menu items, or functions. The sub menu items are organised in tab groups according to how closely they are related to the individual tab group names.</p>
	<p>Clears a measurement from a grid log files cell location or set obstruct, and backspace in an Alpha Edit Box. If you have already saved a measurement and B-Scan to a cell location, use this key to clear the measurement at any time.</p>
	<p>Press to start taking measurements. The readings are displayed in the upper half of the screen and the measurement hot menu items are displayed in the lower half of the screen. Scrolls forward through hot menu items.</p>
	<p>Press to confirm a change or selection. If your gauge is displaying a grid log, this key toggles an advance to row number option.</p>
	<p>In the MENU, MEAS and EDIT functions this key acts as a back or escape function. If your gauge is displaying a grid log, the  key toggles the display options; RF, RECT, B-SCAN or DIGITS. Scrolls back through hot menu items.</p>
	<p>In the menus, scrolls through the menus, increases/decreases values, and toggles functions.</p>
	<p>In menus this key activates list and edit boxes, displays and saves measurements to grid files locations. While making measurements, when COL or ROW is highlighted, opens a log file.</p>
	<p>Press to select a predefined setup (to select a factory or previously saved user setup for a variety of different transducer types and gauge settings).</p>
	<p>Press to switch the gauge on or off. When switching off, the gauge retains all of its settings. If the gauge is idle for 5 minutes, it will switch itself off.</p>

3 GETTING STARTED

3.1 FITTING BATTERIES

Your gauge may be used with dry cell batteries or rechargeable batteries. 3 x LR6 (AA) alkaline batteries are supplied in the kit.

When the battery voltage is low the entire display will start to flash. When this occurs the batteries should be replaced.

To fit or replace batteries:

1. Unscrew battery compartment cover.
2. Referring to battery polarity instructions on rear of gauge, insert batteries into gauge ensuring correct polarity.
3. Replace battery compartment cover.

Remove the batteries from the gauge if it is to remain unused for a long period of time. This will prevent damage to the gauge in the event of malfunction of the batteries.

Note: Alkaline batteries must be disposed of carefully to avoid environmental contamination. Please consult your local environmental authority for information on disposal in your region.

Do not dispose of any batteries in fire.



3.2 FITTING THE TRANSDUCER

To change the delay line, unscrew the end of the transducer and apply couplant to the connecting end of the delay line before screwing together.


The transducer transmits and receives ultrasonic sound waves that the gauge uses to calculate the thickness of the material being measured.

The transducer connects to the gauge via the attached cable, and single coaxial connectors.


Transducers are supplied with two replaceable delay lines, 6.35 mm (1/4") and 12.7 mm (1/2"). The 12.7 mm (1/2") is suitable for most applications and measures steel up to 25 mm. Generally, it should be used to measure thicker materials. It will also dampen the signal of noisy materials, providing better accuracy.

The 6.35 mm (1/4") delay line provides more signal strength and may allow you to measure tough-to-penetrate materials.

Information can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com.



3.3 SWITCHING ON/OFF

To switch on or off, press the on/off key .




The gauge will switch off automatically after 5 minutes of inactivity.

4 THE MENUS





Your gauge has two menu systems:

- Full menu - displays all the functions and settings of the gauge (see also page 27).
- Hot menu - displays a sub-set of functions and settings related to taking measurements.

4.1 FULL MENU

<p>Press MENU once to access the menus...</p>	<p>then press MENU to scroll to the right along the sub menu bar and ESC to scroll left to the sub menu you want.</p>	<p>▲ and ▼ scroll to the desired function.</p>	<p>◀ and ▶ right adjust the selected function.</p>
			

4.2 HOT KEY MENU

<p>Press MEAS once to access the measurement screen. The hot menu functions are displayed at the bottom of the reading screen.</p>	<p>Press MEAS to scroll right along the hot menu functions and ESC to scroll left.</p>	<p>Use ▲, ▼, ◀ and ▶ to adjust the value of the function.</p>	<p>Alternatively, adjust values by pressing ENTER then use ▲, ▼, ◀ and ▶ to scroll and adjust values. Press OK when finished.</p>
			

4.3 OVERVIEW

Throughout these instructions menu locations will be described using a simple system to guide the user. Locations or menu items will be described in the order that they must be navigated to separated by a "/".

For example, to reach the option "Zero Transducer" MENU/PROBE/ZERO TRANSDUCER would be written. After adjusting the desired function press MEAS to return to the measurement screen.

4.4 SELECTING MENU LANGUAGE


The menus can be displayed in English, Spanish, and German.

1. Select MENU/SETUP/LANGUAGE and adjust with LEFT and RIGHT arrows.

5 THE MEASUREMENT SCREEN

Your gauge has four types of measurement screen:

- A-Scan Waveform, RF
- A-Scan Waveform, RECT
- B-Scan
- Digits




To see the measurement screen, press MEAS.

To select which measurement screen to use, press MENU, select DISP, select VIEW and then select RF, RECT, B-SCAN or DIGITS.

5.1 ITEMS COMMON TO ALL MEASUREMENT SCREENS

A number of items are common to all the measurement screens:




A	Battery Icon	Remaining battery life.
B	Repeatability/Stability Indicator	This indicator is used in conjunction with the digital thickness values displayed. When all the vertical bars are fully illuminated and the last digit on the digital thickness value is stable, your gauge is reliably measuring the value.
C	Material Thickness Value/ Material Velocity Value	The thickness or sound velocity of the material under the transducer (type depends upon measurement view).
D	Units	The current measurement units (Metric/English).

E	Measurement View Area	RF, RECT, B-SCAN or DIGITS view area.
F	Measurement Labels Bar	Displays the viewable range and are based on the values of DELAY/B-START and WIDTH/B-DEPTH.
G	Hot Menu	The hot menu contains a selection of the most commonly used options, allowing you to conveniently adjust these to your needs while the graphical display is active.

5.2 RF A-SCAN MEASUREMENT SCREEN

The RF view shows the full sound wave as received by the gauge. The vertical axis indicates the amplitude of the received wave and the horizontal position indicates the time it is received, which is converted into thickness units using the material velocity.

The point on the scan that is being used to calculate the digital thickness reading is displayed as the vertical dashed line (see section 9 on gates). The RF screen is used for gauge setup prior to inspection.



5.3 RECT A-SCAN MEASUREMENT SCREEN

The rectified view shows only half of the waveform, either the positive or negative half depending on the POLARITY selected.


The RECT display is the preferred view for flaw and pit inspections.

5.4 B-SCAN MEASUREMENT SCREEN

The time-based B-Scan display provides a cross sectional view of the material being tested. In this example, the top, or accessible side of the material is represented as 0.00", and the bottom, or blind surface at .500".

This mode is used when you need to inspect the profile of the blind surface. It can also be a useful view when scanning for pits and flaws. The B-Scan display is equipped with a scan bar representing the overall thickness. The scan bar gives the user a visual indication when a flaw or defect passed over during the scan process.

If you are scanning a pipe, for instance, and pass over a pit during the process, the scan bar will quickly deflect and alarm you to go back and search for the defect.




5.5 DIGITS DISPLAY

The digits display shows the thickness as a value using a large font size. This view is used typically when the gauge is being used as a basic thickness gauge. The digits display includes the same scan bar as the B-Scan display.

5.6 CHANGING THE VIEWABLE RANGE

In RF view, RECT view and B-SCAN view, if the waveform around the detection point is not visible on the display, use one of the following methods to adjust the viewable range off the display:



- Change the values of the DELAY and WIDTH functions until the measurement falls inside the viewable range of the display - see instructions below.
- Use the Auto Find function - see “Auto Find” on page 16.

Note: Even if the waveform is outside of the viewable range of the display, a measurement can be taken and viewed using the DIGITS view.

5.6.1 DELAY AND WIDTH

The DELAY is the thickness value from which the A-Scan display starts on the left of the screen. The WIDTH is used to adjust the value at the right side of the screen. Using these two parameters allows the user to zoom in to a specific measurement range and increase the level of detail on the display. For example, if a wall thickness was nominally 25mm and an operator was assessing for corrosion on this wall they might set the DELAY to 10mm and the WIDTH to 20mm to fit as much relevant information on the display as possible.

B-START and B-DEPTH are analogous to DELAY and WIDTH or a B-SCAN display respectively. DELAY and WIDTH or B-START and B-DEPTH may be adjusted in the hot menu or in the DISP section of the main menu.

5.6.2 Adjusting DELAY and WIDTH (or B-START and B-DEPTH)

The quickest way to adjust DELAY and WIDTH is directly from the hot menu. Alternatively, adjust the values using the menus:

1. Select MENU/DISP/DELAY or WIDTH and adjust using LEFT and RIGHT or press ENTER to use the DIGITS EDIT BOX.
2. Press OK to set the value.
3. Press MEAS to return to the measurement.

5.7 GAIN

The gain (the amplitude of the transmitted pulse) can be adjusted to suit a variety of applications. To obtain valid readings the gain must be set to the correct level to give reliable return echoes:

- Too much gain may result in erroneous measurements by detecting noise rather than the material back wall itself.
- Not enough gain may result in intermittent detection. It may also result in lack of detection on internal flaws, pits, or porosity.

The gain setting on your gauge can be compared to the volume control of a home stereo system. If you turn it up too much you cannot hear the music clearly. If it is turned down too much, you cannot hear it at all.

Note: When the echo-echo ThruPaint™ measurement mode is selected, the manual gain feature is disabled and greyed out in the menu items. In this mode, your gauge switches to an automatic gain mode (AGC) that optimises the gain setting automatically.

Your gauge has been optimised for a medium gain setting and for the majority of applications it can be used at this setting. Some applications however may require lower or higher gain settings:

- **Lower values** might be necessary for noisy or granular cast materials. If the reading becomes sporadic and will not settle down or resolve on a thickness value.
- **Higher values** may be necessary when trying to measure a material that is hard to penetrate (due to the material type, or the overall thickness of the material) and when locating fine pits or flaws. In these instances, increase the gain until the stability indicator reports a good measurement.

5.7.1 To Adjust the Gain Value

The quickest way to adjust GAIN is directly from the hot menu. Alternatively, adjust the value using the menus:

1. Select MENU/TUNE/GAIN and adjust using LEFT and RIGHT or press ENTER to use the DIGITS EDIT BOX.
2. Press OK to set the value.
3. Press MEAS to return to the measurement screen.

5.8 THRESHOLD

The threshold is the level of signal amplitude required to trigger a gate and activate the digital thickness reading. Increasing the threshold value decreases the sensitivity of the gauge as a more powerful signal is required to trigger the gate. For example on the A-scan display it may be clear that there is a flaw in the material but the thickness reading is not taking this into account; lowering the threshold has the effect of increasing the sensitivity of the gauge to a level that the flaw can be detected. More information on thresholds can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

5.8.1 To Adjust the Threshold Value

The threshold value may be adjusted from the hot menu when in the P-E GT or E-E measurement mode.

5.9 GATES

Your gauge is equipped with gates which control the time measurement process. Further information on gates can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

5.10 .FRONT PANEL LIGHTS

The green light illuminates when the alarm mode is active and the measured thickness is within limits.

The red light illuminates when the alarm mode is active and the measured thickness is less than the alarm low value, or the measured thickness is greater than the alarm high value.

6 MEASUREMENT - MODES

To select the measurement mode, press MULTI MODE and select the transducer type and measurement mode from the list, see "Setting Up the Gauge" on page 12 for details.

The availability of the modes depends upon the type of transducer fitted to the gauge.

6.1 PULSE-ECHO MODE (P-E)

This mode measures from the initial pulse (sometimes referred to as an artificial zero) to the first echo (reflection). This mode only requires one reflection and it is therefore the most sensitive mode for measuring weak reflections (flaws) typically found when measuring heavily corroded metals. If this mode is used to measure a coated sample, then the thickness of the substrate plus coating will be measured.

6.2 PULSE-ECHO MODE (P-E GT)

This is the same as the standard Pulse-Echo mode described above, but Gate 1 is active.

6.3 ECHO-ECHO MODE (E-E)


This mode measures between two reflections. This technique is commonly used to eliminate errors from surface coatings and also to make measurements in multiple layered materials. The disadvantage is that two echoes are needed which requires a much stronger echo (reflection).

6.4 INTERFACE-ECHO MODE (I-E)


This mode is used with delay line transducers. It measures material thickness from the end of the interface between probe delay line and material and the back wall of the material. This mode is similar to the echo to echo mode as two echoes and two gates are required, however they have different applications.

Interface to echo is mainly used when measuring thicker materials in the medium to high region of the measurement range, only the strong interface echo and the first back wall echo are required. The second back wall echo is much weaker than the first due to attenuation, so in thicker materials it can be lost.


Echo-echo mode is useful for measuring very thin materials at the lower end of the measurement range and the back wall echo is less likely to be lost in the "ring down" or noise from the interface echo.



The pictures show typical A-scans when measuring in interface to echo and echo to echo respectively. Note how in echo-echo mode, the first gate is moved to ignore the first echo from the end of the delay line. Selecting the correct measurement mode and transducer will automatically set the gate positions and hold-off to match.



Interface-Echo (idle)




Interface-Echo (measuring)

I-E Image Key

- A Delay line echo
- B Gate 1
- C Gate 1 detect mark
- D Gate 1
- E Gate 2 start
- F Gate 2 detect mark

E-E Image key

- A Gate 1 detect mark
- B Interface echo
- C Gate 1
- D Gate 2 detect mark
- E Gate 2 start



Echo-Echo Measurement (w/Delay-Line)

Note: The gauge measures the thickness between the two detect marks.

More information on the difference between the Interface to echo and the echo to echo measurement modes can be found on the Elcometer NDT knowledge centre on www.elcometerNDT.com

.

.

7 SETTING UP THE GAUGE


7.1 TRANSDUCER - SETTING TYPE OF

The first step in using your gauge is to select the transducer type from the predefined list of setups stored in the gauge.

Selecting a transducer type and measurement mode optimises all gauge parameters for that particular probe.

Once the setup has been selected, your gauge will recall these settings every time it is switched on. The setup will only change if you select a previously saved setup from the list.

Follow these steps to select your transducer type:

1. Press . A list of setups of measurement modes and transducers is displayed.
2. Use UP and DOWN arrows to scroll through the list until the appropriate type is highlighted and then press ENTER.
Note: Ensure the transducer type you select is the same as the transducer plugged into your gauge; **failure to do this will result in erroneous measurements.**
3. When the CONFIRM screen displays 'OVERWRITE CURRENT SETTINGS', press OK to overwrite the existing transducer type with the newly selected transducer type.

You now need to perform a probe zero before taking measurements.

LOAD SETUP			
1.	E-E DELAY LINE	3/8	
2.	I-E DELAY LINE	3/8	
3.	E-E DELAY LINE	1/2	
4.	I-E DELAY LINE	1/2	
5.	E-E GRAPHITE STEEL		
6.	I-E GRAPHITE STEEL		
7.	I-E GRAPHITE PLASTIC		
8.	E-E PENCIL PTR-100E		
0.33 0.77 1.22 1.66			
DELAY:	0.00	WIDTH:	2.00
POL:	POS	GAIN:	46
GATE1:	0.00	GATE2:	0.00
THR:	2	LOC:	A1
GRID: F-15 RIGHT TRAIL WING			

7.2 TRANSDUCER - ZEROING

Note: This function is only used when using a contact style transducer with a pulse-echo contact setup selected. All the other transducer types use multiple echo modes and the zero function is not needed.

Setting the zero point for the transducer is important in the same way it is important for a mechanical micrometer. Zeroing takes into account slight variations in the manufacturing process for maximum accuracy. If zeroing is not carried out correctly, the measurements taken by the gauge will be in error by some fixed value.

Note: If you intend to switch between measurement modes, setup up the gauge in pulse-echo mode, perform the probe zero, and then save the setup to one of the empty setup locations. Once this is completed, you can switch between modes toggling between two setups.

In order to perform the zero probe routine, your gauge must be in pulse-echo mode.

1. Press MEAS to display the measurement screen.
2. Remove all couplant from the face of the transducer and check that the wearface is clean and free of any debris.

3. Apply a drop of couplant on the transducer and place the transducer as shown in diagram.

Note: Disregard the value displayed; it is not important. What is important is accurately performing these steps to ensure reliability of the zero calculation.

4. Select MENU/PROBE/ZERO TRANSDUCER and press ENTER. The ZERO TRANSDUCER screen is displayed.
5. Press OK (or ESC to cancel).
When the manual probe zero is completed the measurement screen is displayed.
6. Remove the transducer from the probe zero disk.



Your gauge should now be zeroed.

7.3 CALIBRATING - FOR A MATERIAL

Sound travels through different materials at different speeds, and in order to measure these materials accurately the correct sound velocity must be programmed into the gauge. There are three methods of calibrating the gauge.

Known Material Calibration - The material to be measured is selected from a list in the gauge.

Known Velocity Calibration - If the material sound velocity is known this may be entered manually into the gauge.

Known Thickness Calibration - A sample of the material to be inspected is measured using alternative means and then used to calibrate the gauge.

- **One Point** calibration is the simplest and most commonly used calibration procedure with best performance over large measurement ranges
- **Two Point** calibration uses two samples of different thicknesses, with enhanced accuracy over small ranges close to the sample thicknesses used

For the highest measurement accuracy use the known thickness calibration as this takes into account variation in material composition, temperature and a variety of other factors.

*Note: If you create a completely new setup for interface-echo (I-E) mode, a two point calibration **must** be performed.*

7.3.1 Known Material Calibration

If the material velocity is unknown, and a sample thickness cannot be taken from the material, you can choose a material type from a list stored in the gauge. For each material stored in the list there is a corresponding velocity value.

Note: These velocities will not always be an exact representation of the material being tested. Use these values only if a close approximation is acceptable.

1. Select MENU/CAL/MATERIAL and press ENTER.
2. Scroll through the material list until the appropriate material is highlighted
3. Press ENTER to select the material type followed by OK.

Press MEAS to return to the measurement screen.

To achieve the most accurate measurements possible, it is generally advisable to calibrate the gauge to a sample piece of known thickness. Material composition (and thus, its sound-velocity) sometimes varies from lot to lot and from manufacturer to manufacturer. Calibration to a sample of known thickness will ensure that the gauge is set as closely as possible to the sound-velocity of the material to be measured.

7.3.2 Known Velocity Calibration

If the material velocity is known, you can enter the velocity value directly into the gauge. For a list of the sound velocities of common materials see "Sound Velocities of Common Materials" on page 26

1. Select MENU/CAL/VELOCITY and press ENTER to display the DIGITS EDIT BOX.
2. Adjust to match the material velocity using the LEFT, RIGHT, UP and DOWN arrows then press OK.
3. Press MEAS to return to the measurement screen.

7.3.3 Known Thickness Calibration

If the sound velocity of a material is unknown, a sample with one or two known thicknesses can be used to determine the sound velocity.

Note: Although the gauge has a ThruPaint™/coating feature, known thickness calibration must be performed on material with the paint or coating removed.

One-point Calibration: The one point calibration option is most suited for linearity over large ranges. You should always calibrate on high side of the intended measurement range. For example, if the measurement range is 2.54 mm to 25.4 mm (.100" to 1.0"), you should calibrate on a known thickness sample close to 25.4 mm (1.0").

Note: Before you start this calibration procedure, perform a probe zero.

1. Apply a drop of couplant on the transducer and place the transducer in steady contact with the sample or the material being tested. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable.
2. Select MENU/CAL/ONE POINT and press ENTER to display the DIGITS EDIT BOX.
3. Adjust to match the material thickness using the LEFT, RIGHT, UP and DOWN arrows.
4. Press OK to calculate the velocity and return to the measurement screen, or ESC to cancel.

Note: Place the transducer back on the calibration point. The thickness reading should now match the known thickness but if outside tolerance, repeat the steps above.

Two-point Calibration: For improved accuracy over a smaller measurement range, conduct one-point calibration followed by a two-point calibration. For example, if the measurement range is 2.03 mm to 6.35 mm (.080" to 0.250"), perform a one point calibration on a known thickness sample close to 6.35 mm (.250"), followed by a two-point calibration close to 2.03 mm (.080").

1. Conduct a one point calibration routine as described previously in this section. You should conduct this routine at the high end of the measurement range
2. Repeat the routine with another sample at the low end of the measurement range, except this time enter the thickness into the TWO POINT area in the CAL menu.

Note: CHECK YOUR CALIBRATION. Place the transducer back on both calibration points. If the thickness is out of tolerance repeat the steps above.

8 MEASUREMENT - TAKING READINGS

Disclaimer: Inherent in ultrasonic thickness measurement is the possibility that the instrument will use the second rather than the first echo from the back surface of the material being measured. This may result in a thickness reading that is TWICE what it should be.

Responsibility for proper use of the instrument and recognition of this phenomenon rests solely with the user of the instrument.

Other errors may occur from measuring coated materials where the coating is insufficiently bonded to the material surface. Irregular and inaccurate readings may result. Again, the user is responsible for proper use and interpretation of the measurements acquired.

8.1 BEFORE YOU START

- Prepare the surface.
- Ensure the correct transducer is selected and set in the gauge.
- Select the correct measurement mode - see “Measurement - Modes” on page 10.
- Set the zero point of the transducer, if necessary - see:
 - “Transducer - Zeroing” on page 12 and
- Calibrate the gauge - see:
 - “Calibrating - for a Material” on page 13 and
- Choose the measurement view (DIGITS, RF or RECT, or B-SCAN) - see “The Measurement Screen” on page 7.

8.2 PROCEDURE

1. Apply couplant

For the gauge to work correctly there must be no air gap between the transducer and the surface of the material to be measured. This is achieved using a couplant.

Before the transducer is placed on the surface, put a small amount of couplant supplied with the gauge on the surface of the material. Typically a single drop is sufficient.

2. Place transducer onto the surface of the material to be measured

Press the transducer wearface into the couplant. Only moderate pressure is necessary to keep the transducer stationary and the wearface seated flat against the surface of the material.

3. Read display

If six or seven bars of the stability indicator are showing, the display will be reading the correct thickness of the material directly beneath the transducer.

If the stability indicator has fewer than five bars showing, or the numbers on the display seem erratic, check to make sure that there is an adequate film of couplant beneath the transducer, and that the transducer is seated flat against the material. If the condition persists, it may be necessary to:

- adjust the gain, or
- select a different transducer (size or frequency) for the material being measured.

The gauge will perform a number of measurements every second when the transducer is in contact with the surface of the material. The display is updated as each reading is taken.

4. Remove transducer from surface

The display will show the last measurement made.

Note: Occasionally, a small film of couplant will be drawn out between the transducer and the surface as the transducer is removed. When this happens, the gauge may perform a measurement through this couplant film. This phenomenon can be seen when one thickness value is observed while the transducer is in place, and another value is observed after the transducer is removed. If this happens, take the reading again using less couplant.

9 GATES

9.1 INTRODUCTION

The Model PG70ABDL is equipped with gates which control the time measurement process allowing you to measure a specific region on or between waveforms.

Further information on gates may be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

9.2 ADJUSTING THE GATES

In P-E GT mode one gate is available and may be adjusted from the hot menu. In E-E mode both gates may be adjusted from the hot menu or alternatively select MENU/GATE.

10 THRUPAINT™ MEASUREMENT TECHNIQUE

10.1 INTRODUCTION

Your gauge is equipped with a ThruPaint™ measurement mode that uses a multiple echo technique to allow measurement of the material thickness beneath a coating. This is useful for checking the material thickness of painted object.

ThruPaint™ capability is available in E-E mode, to activate ThruPaint™ operation select this measurement mode using the MULTI MODE key and a delay line transducer.

Further information may be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

11 MEASUREMENT - OPTIONS

11.1 AUTO FIND

When using a scan type display, the DELAY and WIDTH (or B-START and B-DEPTH) must be set correctly for the waveform to be shown on the display. If these parameters are set up incorrectly nothing will be seen. The AUTO FIND function solves this problem by automatically adjusting these parameters so that the relevant part of the waveform is shown on the screen.

To use the AUTO FIND function place the transducer on the material to obtain a reading, select MENU/UTIL/AUTO FIND.

11.2 HIGH SPEED SCAN

Although your gauge excels at making single point measurements, it is sometimes desirable to examine a larger region, searching for the thinnest point. The gauge includes a feature, called Scan Mode, which allows it to do just that.

This mode increases the overall repetition rate to a maximum of 32 Hz with a high speed screen refresh rate of 25 times a second.

This feature enables the user to make scanned passes over an arbitrary length of the test material while still maintaining a reasonable representation of thickness over the scanned area or region. This feature can be used in conjunction with High and Low alarm limits features to keep track of both values dynamically.

To enable/disable the high speed Scan Mode:

1. Select MENU/UTIL/SCAN MODE.
2. Use the LEFT and RIGHT arrows to toggle the SCAN MODE on/off.
3. Press MEAS to return to the measurement screen, ready to begin taking readings.

11.3 ALARM MODE

Your gauge includes an Alarm Mode. Set the limits, and if a measurement falls outside of these limits your gauge will signal an alarm (a red light on the front panel of the instrument and/or an audible beep).

This feature may be used for a variety of applications to verify the material is within the manufacturer specifications.

There are two limit values, ALARM LOW and ALARM HIGH. You can choose to activate both or just one of these values depending on your requirements.

To enable/disable Alarm Mode:

1. Select MENU/UTIL/ALARM STATUS.
2. Use the LEFT and RIGHT arrows to toggle the ALARM on/off/audible.
3. Press MEAS to return to the measurement screen, ready to begin taking readings.

To set the Alarm limits:

1. Select MENU/UTIL/ALARM LO LIMIT or ALARM HI LIMIT and press ENTER to display the DIGITS EDIT BOX.
2. Adjust to suit the measurement application using the LEFT, RIGHT, UP and DOWN arrows.
3. Press OK to set the alarm value and return to the menu screen, or ESC to cancel.
4. Press MEAS to return to the measurement screen.

11.4 POLARITY

The polarity that your gauge detects on can be set to either positive or negative to obtain the best detection results depending on the specific measurement conditions of your application. Polarity affects both the gate (above or below the x axis in the RF A-Scan) and the Rectified A-Scan display (whether the top or bottom half of the RF display is shown).

For further information refer to the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

To adjust POLARITY:

1. Set the measurement screen view to RF, MENU/DISP/VIEW.
2. Select MENU/TUNE/POLARITY.

11.5 RECTIFIED WAVEFORM DISPLAY OPTIONS

When the measurement screen is set to RECT, you have the option of displaying the waveform filled in black, or outlined (unfilled).

To set this option:

1. Press MENU, select DISP, select VIEW and then select RECT to set the RECT display view.
2. Press MENU, scroll to the TUNE menu and then highlight the RECT WAVEFORM function.
3. Use LEFT and RIGHT arrows to adjust the value of RECT WAVEFORM (FILLED, OUTLINE).
4. Press MEAS to return to the measurement screen.

Your gauge is equipped with a data logger. With a data file open, all your measurements are saved into the file for later review and download to PC.

12 MEASUREMENT - RECORDING YOUR READINGS

12.1 ABOUT THE DATA LOGGER

With a data file open, as you take measurements, the measurement data is stored in files in the gauge memory in Grid format similar to a spreadsheet format in which each cell is used to store a reading. Cells are referenced by the row number (1 to 999) and the column label (A to ZZ).

Data logger filename character sets

Any combination of the following characters can be used for file names:

- Numeric characters: 0 - 9
- Alpha Characters: A - Z
- Special Characters: ! ' _ # space / . - ()

What measurement data is saved

When a measurement is taken (irrespective of log file format), the following information is saved:

- The reading value.

- A screenshot, the nature of which will depend on what view the gauge was in at the time the reading was taken. For example, if the view was in B-SCAN, then a B-SCAN screenshot will be saved with the reading. This 'Save Graphics' option can be toggled on/off.

Memory capacity

You can create and save as many data files as required up to the maximum capacity of the gauge memory (32 Mbit). If you try to create a new file which exceeds the memory capacity, the gauge will display an error message. Saved data must be deleted in order to make the space available.

Save Graphics Option	Memory Capacity (readings)
On	12 000 +
Off	210 000 +

12.2 CREATING A NEW DATA LOGGER FILE - GRID FORMAT

To create a GRID log data file:

1. Select MENU/DATA/NEW and press ENTER to continue.
2. Fill in a name and a note (if desired) for your data logger file.
3. Select the size of the grid. Grid positions are denoted by a number and a letter, where the letter is the column and the number is the row.
Use TOP LEFT and LOWER RIGHT to define the size of the grid. For example, a with the TOP LEFT set to A001 and LOWER RIGHT C003 would produce a 3x3 grid.
The grid can have a maximum of 52 columns and 999 rows.
4. Set the Auto Increment direction. This option allows you to select which direction the cursor moves after a reading is stored in terms of compass points. For example NORTH would move the cursor up a row, and WEST would move a column left.
5. Choose whether to activate SAVE GRAPHICS or not (snapshot of the A OR B scan on screen).
6. Finally create the log by scrolling to CREATE LOG, pressing ENTER and then OK to confirm. The measurement grid is now displayed along with the grid name on screen.

12.3 HANDLING LOGGER FILES

Once created, logger files may be opened or closed using the functions "OPEN" and "CLOSE". Closing logger files places the gauge in immediate mode and will prevent accidental saving of data into an inappropriate log.

12.4 STORING READINGS IN A DATA LOGGER FILE

1. Create a new data logger file or open an existing file.
The grid is displayed in the lower half of the measurement screen.
Note: Once the file is open, it will remain open until it is closed or another file is opened. If the gauge is switched off, the file will be opened automatically when the gauge is switched on again. Press the ENTER key to display the file from the measurement screen.
2. If you want to save the reading to a particular cell location, scroll to the desired cell.
Note: The cell location must be empty. If it already contains a reading and you want to save a new reading to the same location, refer to the instructions given in "Viewing and Deleting readings" on page 19.
3. Take a reading and then press ENTER.
The reading value is saved in the file at the location selected and the cursor advances to the next cell according to the rules set for the data logger file:

- If INCR. DIR is set to NORTH, EAST, SOUTH or WEST, the cursor will advance one cell in the chosen direction. When the cursor reaches the last cell in the row or column it will return to the other end of the row or column.

Note: If you try to save a reading into a cell location which already contains a reading value, a warning message is displayed (see Deleting a reading).

4. To advance to a specific row number, press OK enter the row number. Press OK to advance directly to that row number in the grid log.
5. To toggle the display between DIGITS view and B-SCAN view, press ESC.
6. If you are unable to take a measurement due to the measurement location being physically inaccessible, press CLR.
The cell location in the data file is marked OBST (Obstruct).
7. The display of the log data file on the measurement screen can be switched on and off:
 - To switch off, press MEAS
 - To switch on, press ENTER.

12.5 VIEWING AND DELETING READINGS

With a data file open:

1. Use the arrows to scroll through the cells in the data file.
As the cursor is moved to a different cell, the display is updated with the display view saved with the reading (if SAVE GRAPHICS was set to YES). Readings stored in memory are indicated by MEM in the top left corner of the measurement screen (in place of the bars of the stability indicator).
2. To delete a reading, scroll to the cell location, press CLR and then OK (or ESC to cancel).
The reading is deleted and if you wish you can now take another measurement and save the reading in this cell location.

12.6 EDITING A DATA LOGGER FILE

You can edit the following fields of data files:

- NAME, NOTE, and INCRement DIRection

To edit a file:

1. Open the data file. (Select MENU/DATA/OPEN)
2. Select MENU/DATA/EDIT and press ENTER
The EDIT GRID screen is displayed and lists all the fields which can be edited.
3. Scroll to the field you want to edit, press ENTER and then adjust the contents of the field using the techniques previously described to create a data file - see page 18.
4. When finished, scroll to SAVE CHANGES, press ENTER and then OK (or ESC to cancel).

12.7 DELETING A DATA LOGGER FILE

1. Select MENU/DATA/DELETE ONE GRID and press ENTER.
The DELETE GRID screen is displayed and lists all the data files stored in your gauge memory.
2. Scroll through the list until the data file you want to delete is highlighted.
3. Press OK (or ESC to cancel).

The file is deleted.

12.8 DELETING ALL DATA LOGGER FILES

Note: This will delete all the data logger files in gauge memory - use with caution.

1. Select MENU/DATA/DELETE ALL GRIDS.
2. Press ENTER and then OK to confirm (or ESC to cancel).

The data logger memory is erased - all files are deleted.

13 GAUGE SETUPS

Your gauge contains 64 configurable preset locations in which you can store custom gauge setups, each one optimised for a specific measuring application. These gauge setups can save time when conducting routine inspections of the same job or project. This feature also helps to eliminate error between two or more users during the setup and calibration process.

The setups store:

- Measurement mode
- Transducer type
- Gain setting
- Scan mode setting
- Alarm settings
- Display type setting

As well as storing the setups in your gauge, you can also store the setups on a computer and transfer them bi-directionally using the PC interface software included with the gauge.

The factory supplied setups stored in the gauge cover some of the more typical applications commonly used with this type of instrument. These setups can be recalled, modified, and overwritten to one of 64 setup locations. Therefore, these factory setups can also be considered a good starting point to be modified for custom applications.

The PC interface software includes a default setup file that can be uploaded to the gauge at any time to restore factory settings. However, you should consider saving modified setups to an empty location rather than overwriting the factory setups in your gauge.

13.1 OPENING A SETUP

You can open a setup by pressing , or use the menus as follows:

1. Select MENU/SETUP/OPEN and press ENTER to display the SETUP LIST BOX.
2. Scroll through the list of setups until the required setup is highlighted.
3. Press ENTER to activate the confirmation screen.
4. Press OK to load the setup from memory.
1. Press MEAS to return to the measurement screen.

LOAD SETUP	
1. E-E DELAY LINE 3/8	
2. I-E DELAY LINE 3/8	
3. E-E DELAY LINE 1/2	
4. I-E DELAY LINE 1/2	
5. E-E GRAPHITE STEEL	
6. I-E GRAPHITE STEEL	
7. I-E GRAPHITE PLASTIC	
8. E-E PENCIL PTR-100E	
SETUP DATA UTIL XFER	
OPEN	
SAVE	1
DEFAULT SETUP	
LANGUAGE	ENGLISH


13.2 SAVING AND EDITING A SETUP

Once the parameters and features have been adjusted for an application, you can save these setting to a specific setup location for future use.

It is sometimes necessary to rename a previously saved setup, or add additional comments about a particular setup. The setup name may have been entered incorrectly, or you may need to use the setup for a completely different project. An inspector's name or other comments about the project may also be required for additional documentation purposes.

The following procedures outline the necessary steps for saving and editing a setup:

1. Select MENU/SETUP/SAVE and press ENTER to display the SAVE SETUP EDIT BOX.
2. Scroll to NAME and then press ENTER to edit its value:
 - When you have finished, press OK to enter the value.
3. If you want to add a note, repeat step 2 for NOTE.
4. When you have finished, scroll to SAVE SETUP and press ENTER. The setup list screen is displayed.
5. Scroll through the list of setups until the required location to save the setup is highlighted.
6. Press OK to activate the confirmation screen.
7. Press OK to save the SETUP, or ESC to cancel.



Note: The Name and Note parameters of a Setup can be edited at any time by repeating the Save Setup routine described above. Therefore, the Save Setup function can also be considered an Edit Function.

13.3 USING THE DEFAULT SETUP

Your gauge includes a default setup which you can use (as a last resort) if there are no other setups stored in the gauge. This gives you the ability to load and modify a basic setup as follows:

1. Select MENU/SETUP/DEFAULT SETUP and press ENTER to activate the confirmation screen.
2. Press OK to confirm.
3. Press OK again to confirm.



14 DATA TRANSFER SOFTWARE

Software is available which allows data to be transferred from your gauge to a PC. Presently Elcometer supplies ElcoMaster™ software for this purpose.

To set-up other types of communications software:

1. Start the communications software.
2. Configure the software using the following parameters:
Data Bits - 8, Parity - None, Stop Bits - 1, Baud Rate 1200 (to print a report), or 9600 to transfer data file.

Note: A report can be printed to a communications program (i.e. HyperTerminal), or printed to a serial printer using A4 or 8.5" x 11" paper.

3. Set the communications software COM port to the port number that the gauge is connected to.

14.1 TRANSFERRING MEASUREMENT DATA TO YOUR COMPUTER

14.1.1 RS-232 Connector

The RS-232 connector, located on the bottom end cap of the gauge, is a 2 pin female Lemo connector. It is designed to connect directly from the gauge to a standard AT serial port on a PC. A Lemo to 9 pin serial cable is supplied with the gauge.

Note: This connector is also used to upgrade the gauge with the latest version of firmware.

14.1.2 USB to Serial Converter

Some newer laptop computers do not have standard serial ports. In this case, use the USB to Serial converter supplied with the gauge.

14.1.3 Computer System Requirements

ElcoMaster™ is compatible with any Windows computer system running Windows XP or above.

14.1.4 Using the XFER menu

The XFER menu of your gauge is used in conjunction with the ElcoMaster™ PC software. The steps below outline the procedure for accessing the XFER menu and basic operation as follows:

1. Scroll to the XFER section of the main menu.
2. Press the ENTER key to activate the option selected.
3. Once the Backup or Restore function has been completed, press the MEAS key once to return to the menu items, or twice to return to the measurement mode..

15 STORAGE



Your gauge has a Liquid Crystal Display. If the display is heated above 50°C (120°F) it may be damaged. This can happen if the gauge is left in a car parked in strong sunlight. Always store the gauge in its case when it is not being used.

If the gauge is to remain unused for long periods of time, remove the batteries and store them separately. This will prevent damage to the gauge in the event of malfunction of the batteries.

16 MAINTENANCE

You own one of the finest corrosion gauges in the world. If looked after, it will last a lifetime.

16.1 FAULTS

Your gauge is designed to give many years reliable service under normal operating and storage conditions. The gauge does not contain any user-serviceable components. In the unlikely event of a fault, the gauge should be returned to your local Elcometer NDT supplier or directly to Elcometer NDT. The warranty will be invalidated if the instrument has been opened.

16.2 TRANSDUCER

The transducer will wear with repeated use. Transducer life depends on the number of measurements taken and the manner in which readings are taken. To extend transducer life, always set the transducer down so that it is perpendicular to the panel surface. Dragging the transducer along the surface will reduce the life of the transducer. Replacement transducers are available from your local Elcometer NDT supplier or directly from Elcometer NDT.

17 TECHNICAL SPECIFICATION

Measurement Rate	Manual	4 readings per second
	Scan mode	32 readings per second
Measuring Range ^a - Sound Velocity		1250 m/s to 10000 m/s (0.0492 in/μs to 0.3930 in/μs)
Measuring Range - Thickness	Pulse-Echo P-E (contact) on steel	1.000 mm to 254 mm (0.040" to 10.0")
	Pulse-Echo P-E (contact) on plastic	0.254 mm to 254 mm (0.010" to 10.0")
	Interface-Echo I-E on steel	1.27 mm to 25.4 mm (0.050" to 1.0")
	Interface-Echo I-E on plastic	0.127 mm to 25.4 mm (0.005" to 1.0")
	Echo-Echo E-E (contact) on steel	2.54 mm to 76.2 mm (0.10" to 3.0") - ThruPaint™
	Echo-Echo E-E on steel	0.15 mm to 12.7 mm (0.006" to 0.50")
Measurement Resolution	Sound Velocity	1 m/s (0.0001 in/μs)
	Thickness	0.001 mm (0.0001") or 0.01 mm (0.001") - selectable
Velocity Calibration Range		1250 m/s to 10000 m/s (0.0492 in/μs to 0.3937 in/μs)
Weight (including batteries)		380 g (13.5 oz)
Dimensions (W x H x D)		63.5 mm x 165 mm x 31.5 mm (2.5" x 6.5" x 1.24")
Gauge Operating Temperature		-10°C to 60°C (14°F to 140°F)
Case		Aluminium case with gasket sealed end caps and waterproof membrane keypad
PC Connection		RS232 serial port. Windows PC interface software
Display		Backlit VGA greyscale display (240 x 160 pixels). Viewable area 62 mm x 45.7 mm (2.4" x 1.8"). EL backlit (on/off/auto).
Power Source		Three 1.5 V AA alkaline or rechargeable cells. Typically operates for 200 hours on alkaline cells and 120 hours on rechargeable cells (charger not included.) <i>Note: Alkaline cells must be disposed of carefully to avoid environmental contamination. Please consult your local environmental authority for information on disposal in your region. Do not dispose of any cells in fire.</i>

a. Measuring Range depends on material, surface conditions and the transducer selected.

18 WARRANTY

Elcometer NDT warrants your gauge against defects in materials and workmanship for a period of two years from receipt by the end user.

Additionally, Elcometer NDT warrants transducers and accessories against such defects for a period of 90 days from receipt by the end user. If Elcometer NDT receives notice of such defects during the warranty period, Elcometer NDT will either, at its option, repair or replace products that prove to be defective. The warranty will be invalidated if the instrument has been opened.

18.1 EXCLUSIONS

The above warranty shall not apply to defects resulting from: improper or inadequate maintenance by the customer; unauthorised modification or misuse; or operation outside the environmental specifications for the product.

Elcometer NDT makes no other warranty, either express or implied, with respect to this product. Elcometer NDT specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Some states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion may not apply to you. However, any implied warranty of merchantability or fitness is limited to the two-year duration of this written warranty.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from country to country, state to state or province to province.

18.2 OBTAINING SERVICE DURING WARRANTY PERIOD

If your hardware should fail during the warranty period, contact Elcometer NDT and arrange for servicing of the product. Retain proof of purchase in order to obtain warranty service.

For products that require servicing, Elcometer NDT may use one of the following methods:

- Repair the product
- Replace the product with a re-manufactured unit
- Replace the product with a product of equal or greater performance
- Refund the purchase price.

18.3 AFTER THE WARRANTY PERIOD

If your hardware should fail after the warranty period, contact Elcometer NDT for details of the services available, and to arrange for non-warranty service.

19 SPARES & ACCESSORIES

19.1 TRANSDUCERS

Elcometer NDT gauges are **not** supplied with a transducer as standard - this must be ordered separately.

The transducers listed below are the most commonly used however, Elcometer NDT offer a wide range of other transducers to suit various applications.

Further information on the transducers available and their applications can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

Description

15 MHz Single Element Delay Line Transducer
 20 MHz Single Element Delay Line Transducer
 Delay Line Tip, Acrylic, ¼" Diameter x ½" Length
 Delay Line Tip, Graphite, ¼"

Sales Part No.

TX15 MOCM
 TX20 MOCM
 TD-24033-6
 TD-24033-8

19.2 CALIBRATION BLOCKS

Elcometer NDT offer a comprehensive range of calibration blocks to suit a wide range of applications and standards.

Selecting the correct calibration block for the application is essential to ensure accurate evaluation. The form, shape and material of the calibration block should be appropriate for the material being inspected. Any artificially induced flaw should closely resemble that of the actual flaw being tested for.

The calibration blocks listed below are a selection of those available - details of the full range can be found on www.elcometerNDT.com

Description	Sales Part No.
Calibration Block: 8 Step; 1 - 8mm	TW-24005-*
Calibration Block: 10 Step; 2 - 20mm	TW-24006-*
Calibration Block: 10 Step; 2.5 - 25mm	TW-24007-*
Replace * with S1018 = 1018 Steel Block; A = Aluminium Block; SS = Stainless Steel Block; T = Titanium Block.	

19.3 ULTRASONIC COUPLANT

Each gauge is supplied with a 120ml (4 fl oz) bottle of standard ultrasonic couplant. Replacement bottles and couplant for high temperature applications are available from your local Elcometer NDT supplier or directly from Elcometer NDT.

Description	Sales Part No.
Ultrasonic Couplant, 120 ml (4 fl oz)	TC-24034-1
Ultrasonic Couplant, 360 ml (12 fl oz)	TC-24034-2
Ultrasonic Couplant, High Temperature 510°C (950°F), 60 ml (2 fl oz)	TC-24034-9

Note: A wide range of other transducers and accessories is available - see www.elcometerNDT.com for details.

19.4 MISCELLANEOUS

Description	Sales Part No.
RS232 Cable USB to Serial Converter	TL-24031

20 CONDITION AND PREPARATION OF SURFACES

Information can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

21 APPLICATION NOTES

Information can be found on the Elcometer NDT Knowledge Centre on www.elcometerNDT.com

22 SOUND VELOCITIES OF COMMON MATERIALS

Material	Sound velocity	
	(m/s)	(in/ μ s)
Aluminium	6350	0.250
Bismuth	2184	0.086
Brass	4394	0.173
Cadmium	2769	0.109
Cast Iron	4572	0.180 (Approx.)
Constantan	5232	0.206
Copper	4674	0.184
Epoxy Resin	2540	0.100 (Approx.)
German Silver	4750	0.187
Glass, Crown	5664	0.223
Glass, Flint	4267	0.168
Gold	3251	0.128
Ice	3988	0.157
Iron	5893	0.232
Lead	2159	0.085
Magnesium	5791	0.228
Mercury	1448	0.057
Nickel	5639	0.222
Nylon	2591	0.102 (Approx.)

Material	Sound velocity	
	(m/s)	(in/ μ s)
Paraffin	2210	0.087
Platinum	3962	0.156
Plexiglas	2692	0.106
Polystyrene	2337	0.092
Porcelain	5842	0.230 (Approx.)
PVC	2388	0.094
Quartz Glass	5639	0.222
Rubber, Vulcanised	2311	0.091
Silver	3607	0.142
Steel	5918	0.233
Steel, Stainless	5664	0.223
Stellite	6985	0.275 (Approx.)
Teflon	1422	0.056
Tin	3327	0.131
Titanium	6096	0.240
Tungsten	5334	0.210
Water	1473	0.058
Zinc	4216	0.166

23 THE MENU COMMANDS

Menu	Function	Description
PROBE	ZERO TRANS-DUCER	Zeros your gauge in much the same way that a mechanical micrometer is zeroed. If your gauge is not zeroed correctly, all of the measurements made may be in error by some fixed value. You can choose between automatic zero or manual zero.
	PULSE	Your gauge has adjustable pulse width for both high penetration and resolution applications. The pulse width refers to the duration of time the pulser is on. The options are SPIKE, THIN, and WIDE.
CAL (CALIBRATION)	UNITS	Toggle between Metric (millimetres) or English (inches) units.
	VELOCITY	This function calibrates your gauge to a specific material type by entering a material velocity.
	ONE POINT	Performs a single point calibration. This function allows you to automatically calculate the velocity by entering a known sample thickness.
	TWO POINT	Performs a two-point calibration. This function allows you to automatically calculate the velocity by entering a second known sample thickness.
	MATERIAL	Select the material velocity from a chart of basic material types when a known sample thickness, or material velocity cannot be obtained.
DISP (DISPLAY)	VIEW	Choose between RF wave, RECT (rectified) wave, BSCAN (cross section), and DIGITS (large digits) views.
	BACKLIGHT	Choose between OFF, ON, AUTO, or INVERT backlight.
	CONTRAST	Adjust the display contrast for variable light conditions.
	DELAY	Adjust where the left side of the display window starts according to thickness, in inches or millimeters.
	WIDTH	Set the overall depth of the viewable measurement area. It functions a lot like a zoom on a camera.

Menu	Function	Description
TUNE	GAIN	Increases or decreases the overall amplitude of the signal. Gain is similar to the volume control on a stereo receiver.
	AGC	When operating in echo-echo mode, the gauge adjusts the gain automatically. Alternatively, the AGC can be manually controlled.
	THRESHOLD	Adjust the sensitivity level of the gauge. The amplitude of the signal must reach and exceed the threshold level before a measurement is detected.
	POLARITY	The gauge operates on a zero crossing detection principle. This feature toggles which stroke of the cycle the crossing detection uses, either positive or negative.
	RECT WAVE-FORM	Toggles between an outlined or filled view option when the display setting is in RECT (rectified) wave mode.
GATE	MEASURE MODE	Select the measurement mode for different application requirements. The modes are P-E (pulse-echo), E-E (echo-echo) and I-E (interface-echo).
	GATE 1	Set the value of Gate 1. Gate 1 can be used in pulse-echo, echo-echo and interface-echo measurement modes.
	GATE 2	Set the value of Gate 2. Gate 2 can be used in echo-echo and interface-echo measurement modes only.
SETUP	OPEN	Displays a list of factory and user-defined setups currently stored in memory. These setups can be recalled and used at any time.
	SAVE	Save a custom setup that you have modified or created.
	DEFAULT SETUP	Loads a basic default setup. Use only as a last resort if the setups in your gauge have been corrupted and a computer is not accessible.
	LANGUAGE	Select the menu language
DATA	NEW	Creates a new alpha numeric grid file with auto identifiers. You can customise the file according to your requirements.
	EDIT	Modify the parameters of grid files previously saved. <i>Note: Predefined coordinates cannot be changed once they have been created.</i>
	OPEN	Recalls existing grid files from gauge memory.
	DELETE ONE GRID	Deletes a single file from the gauge memory.
	DELETE ALL GRIDS	Deletes all files from the gauge memory.

Menu	Function	Description
UTIL (UTILITIES)	AUTO FIND	Automatically locates the detection point if the measurement is out of the viewable display area.
	SCAN MODE	Enables a high speed scan mode that increases the sample rate to 32 measurements per second.
	ALARM STATUS	Toggles alarm mode on, off, or audible.
	ALARM LO LIMIT	Sets the LO (Low) limit parameter. If the measurement falls below this value, a red light will illuminate and the alarm will sound.
	ALARM HI LIMIT	Sets the HI (High) limit parameter. If the measurement exceeds this value, a red light will illuminate and the alarm will sound.
XFER (TRANSFER)	BACKUP SETUPS	Allows you to backup the setups currently stored in your gauge to a computer via the RS232 port.
	RESTORE SETUPS	Allows you to restore setups saved on a computer to your gauge via the RS232 port.
	BACKUP GRID	Allows you to backup grid files stored in your gauge to a computer via the RS232 port.
	RESTORE GRID	Allows you to restore grid files saved on a computer to your gauge via the RS232 port.
	ABOUT	Provides Elcometer NDT contact information and your gauge software version. Refer to the help section of your gauge ElcoMaster™ for a complete electronic manual covering data transfer.