

Measurement Modes on the Elcometer 480 Glossmeters

The Elcometer 480 Glossmeters have three measurement modes.

Standard Mode for individual spot measurements.

Scan Mode: scan the surface to provide the average, highest and lowest reading.

Auto Repeat Mode which automatically measures individual readings at a user definable rate.

Standard Mode: Press the button to take an individual spot measurement.

Scan Mode: Measuring at a rate of 10 readings per second, the glossmeter scans the surface and when complete displays the average, highest and lowest values.

Auto Repeat Mode: Individual readings are automatically taken by the glossmeter at a user definable rate, between 10 to 180 readings per minute.

The Elcometer 480: setting the benchmark for hand-held gloss measurement.